



80mm downpipe cut line only. See above for fitting Curve to 65mm downpipe.


CULVE

NO GLUE REQUIRED

Cutting Template & Installation Guide

Apply this template to your downpipe as a cutting guide.

Curve is best installed at an easily accessible height for ease of maintenance. If on a tank system Curve must be at least 300mm above the tank inlet and overflow.



Note: Downpipe clip fixings not included – purchase separately to suit your cladding type. Curve is not designed for rectangular downpipe or round downpipe larger than 80mm OD. If installing Curve on 65mm uPVC downpipe extra adaptors are required. Ask your store for item code CURVE2.RA65.

Please refer to the Curve® technical section at **www.marley.co.nz** for additional information.

